WATCH DISPLAY



- A. Crown
- B. 24 Hour Dial
- C. Hour Hand
- D. Minute Hand

TIMESETTING

This watch features hour, minute and second hands.

- Pull the Crown (A) out to position "1" and turn the crown forward or backward to set the time.
- **2.** Once the correct time is set, push the crown back into the original zero (0) position.



INSTRUCTION MANUAL



Visit us at, www.stauer.com to learn more about the fantastic benefits of owning a Stauer Watch!

www.stauer.com