

Compact Room Heater – 1200W

Instruction Manual
H94359

IMPORTANT SAFETY INSTRUCTIONS

Please read this manual carefully before using your heater. Keep it for future reference. Failure to follow instructions may result in electric shock, fire, or injury.

- ❑ Use only with the correct voltage compatible with UK mains supply.
- ❑ Plug into a properly grounded, accessible wall socket.
- ❑ Keep the heater upright during operation.
- ❑ Do not cover or obstruct air inlets and outlets.
- ❑ Keep away from curtains, papers, furniture, and other flammable materials.
- ❑ Do not expose the power cable to sharp edges, liquids, or heat.
- ❑ If the cable is damaged, it must be replaced by a qualified person.
- ❑ Do not attempt to dismantle or modify the heater.
- ❑ Keep out of reach of children. This product is not a toy.
- ❑ Discontinue use if the heater is dropped or shows visible damage.
- ❑ Do not immerse the appliance in water or other liquids.

⚠ Warning: Improper use may compromise safety.

PRODUCT DESCRIPTION

This compact 1200W heater provides fast, efficient warmth with a lightweight design, making it ideal for use in bedrooms, offices, and small living areas.

- ❑ Compact and portable.
- ❑ Energy-efficient PTC heating element.
- ❑ Overheat protection for safety.
- ❑ Adjustable thermostat for comfort.

SPECIFICATIONS

Feature	Detail
Power Consumption	1200 W
Voltage	220–240 V, 50/60 Hz
Heating Element	PTC ceramic
Safety Features	Overheat protection
Unit Dimensions	(ask supplier to confirm)
Weight (Net)	(ask supplier to confirm)

OPERATING INSTRUCTIONS

1. Setup

- Place the heater on a stable, flat surface.
- Ensure air inlets/outlets are not obstructed.

2. Operation

- Plug the heater into a suitable mains socket.
- Use the switch/thermostat knob to set the desired heat output.
- Allow a few minutes for the heater to reach optimal performance.

3. After Use

- Switch the heater off and unplug from the wall socket.
- Allow to cool before moving or storing.

MAINTENANCE & STORAGE

- Switch off and unplug before cleaning.
- Clean exterior with a soft, dry cloth. Do not use detergents or immerse in water.
- Store in a cool, dry place away from direct sunlight.

DISPOSAL & ENVIRONMENTAL INFORMATION

This product falls under the WEEE (Waste Electrical & Electronic Equipment) regulations.

- Do not dispose of with household waste.
- Take to an authorised collection facility for recycling.
- Packaging materials should be recycled where possible.

COMPLIANCE & CERTIFICATIONS

This product complies with applicable UK/EU regulations and standards, subject to certification:

- UKCA / CE – Electrical safety and EMC compliance
- RoHS – Restriction of hazardous substances
- WEEE – Electronic waste directive

(Add certification logos)

WARRANTY

This product is guaranteed for 12 months against defects in materials or workmanship. Excludes damage caused by misuse, accidents, or unauthorised modifications.

For after-sales support, visit:

www.hssuk.co.uk

MANUFACTURER DETAILS

Direct Response Marketing Group Ltd (manufacturer)
Trading as Home Shopping Selections
Website: www.hssuk.co.uk
Product Origin: Made in China