

ThermaGlove – Heated Winter Gloves

Instruction Manual

H94361 (Medium) / H94362 (Large)

IMPORTANT SAFETY INSTRUCTIONS

Please read this manual carefully before using your heated gloves. Keep it for future reference. Failure to follow instructions may result in overheating, burns, electric shock, or injury.

- ❑ Use only with the supplied USB power cable/power bank.
- ❑ Do not connect to uncertified or damaged USB adapters.
- ❑ Keep gloves dry. Do not immerse in water or expose to rain.
- ❑ Do not wear while sleeping.
- ❑ Do not use on infants, pets, or people unable to remove the product unaided.
- ❑ Not suitable for use by persons with reduced physical, sensory, or mental capabilities without supervision.
- ❑ Inspect the product before use. Discontinue use if damaged, wet, or showing visible wear.
- ❑ Do not pierce, crush, or attempt to repair the gloves.
- ❑ Keep away from fire, heaters, or high heat sources.
- ❑ Store safely when not in use.

⚠ Warning: Improper use may void your warranty and compromise safety.

PRODUCT DESCRIPTION

The ThermaGlove Heated Winter Gloves are designed to provide warmth and comfort in cold conditions using an integrated USB-powered heating element.

- ❑ USB-powered heating (portable, compatible with power banks).
- ❑ Soft fleece lining for comfort.
- ❑ Anti-slip exterior for grip.
- ❑ Three heating levels with LED indicators.

SPECIFICATIONS

Feature	Detail
Power Supply	USB 2.0 / 5V ($\geq 2.0\text{A}$ recommended)
Heating Temperature	Approx. $45^{\circ}\text{C} \pm 5^{\circ}\text{C}$
Heating Time	Up to 3 hours with a 10,000 mAh power bank
Material (Exterior)	PU / Anti-slip fabric
Lining	Fleece
Sizes	Medium, Large

Feature	Detail
Safety Features	Overheat protection

OPERATING INSTRUCTIONS

1. Setup

- Connect the USB plug to a suitable 5V 2.0A (or higher) power source such as a power bank, laptop, or USB adapter.
- Ensure cable and connectors are undamaged before use.

2. Operation

- Switch Version: Press “I” to switch on. Press “O” to switch off.
- Three-Speed Version:
 - Hold the button for 3 seconds to switch on.
 - Red light = High heat (100%)
 - Blue light = Medium heat (70%)
 - Green light = Low heat (30%)
 - Hold button again for 3 seconds to switch off.

3. After Use

- Disconnect from the power source.
- Allow to cool before storing.

MAINTENANCE & STORAGE

- Do not machine wash, dry clean, or immerse in water.
- Wipe clean with a slightly damp cloth, ensuring USB ports stay dry.
- Store in a dry, cool place away from direct sunlight.
- Do not bend or crush the heating elements.

DISPOSAL & ENVIRONMENTAL INFORMATION

This product falls under the WEEE (Waste Electrical & Electronic Equipment) regulations.

- Do not dispose of with household waste.
- Dispose via appropriate electronic waste recycling channels.
- Recycle packaging materials where possible.

COMPLIANCE & CERTIFICATIONS

This product complies with applicable UK/EU regulations and standards, subject to certification:

- UKCA / CE – Electrical safety and EMC compliance
- RoHS – Restriction of hazardous substances
- WEEE – Electronic waste directive

(Logos to be added)

WARRANTY

This product is guaranteed for 12 months against defects in materials or workmanship.
Excludes damage caused by misuse, accidents, water ingress, or unauthorised modifications.

For after-sales support, visit:

www.hssuk.co.uk

MANUFACTURER DETAILS

Direct Response Marketing Group Ltd (manufacturer)

Trading as Home Shopping Selections

Website: www.hssuk.co.uk

Product Origin: Made in China